

VIPER 150W LED

Moving head

Channel	Value	Description
1	Pan	Pan movement
2		Pan fine
3		Tilt movement
4		Tilt fine
5	0-255	Pan & tilt fast to slow
6 Dimmer		Linear dimming
7 Shutter	0-4	Shutter off
	5-64	Random shutter
	65-128	Regular shutter
	129-160	From dark to bright shutter
	161-192	From bright to dark shutter
	193-224	Shutter effect1
	225-249	Shutter effect2
	250-255	Shutter on
8 Color	0-8	White
	9-16	Color1+white
	17-24	Color1
	25-32	Color1+color2
	33-40	Color2
	41-48	Color2+color3
	49-56	Color3
	57-64	Color3+color4
	65-72	Color4
	73-80	Color4+ color 5
	81-88	Color 5
	89-96	Color 5+ color 6
	97-104	Color 6

VIPER 150W LED

Moving head

Channel	Value	Description
8 Color	105-112	Color 6+ color7
	113-120	Color 7
	121-128	Color 7+ color 8
	129-136	Color 8
	137-144	Color 8+white
	145-200	Clockwise flow
	201-255	Counter-clockwise flow
9 Fixed gobo	0-6	White
	7-13	Gobo1
	14-20	Gobo 2
	21-27	Gobo 3
	28-34	Gobo 4
	35-41	Gobo 5
	42-48	Gobo 6
	49-55	Gobo 7
	56-62	Gobo 8
	63-69	Gobo 9
	70-76	Gobo 9 shake
	77-83	Gobo 8 shake
	84-90	Gobo 7 shake
	91-97	Gobo 6 shake
	98-104	Gobo 5 shake
	105-111	Gobo 4 shake
	112-118	Gobo 3 shake
	119-125	Gobo 2 shake
	126-132	Gobo 1 shake
	133-192	Gobo Clockwise flow
	193-255	Gobo Counter-clockwise flow
10 Rotating gobo	0-8	White
	9-17	Gobo1
	18-26	Gobo 2
	27-35	Gobo 3
	36-44	Gobo 4



VIPER 150W LED

Moving head

Channel	Value	Description
10 Rotating gobo		Gobo 5
		Gobo 6
		Gobo 6 shake
		Gobo 5 shake
		Gobo 4 shake
		Gobo 3 shake
		Gobo 2 shake
		Gobo 1 shake
		White shake
		Clockwise gobo flow
		Counter-clockwise gobo flow
11 Gobo rotation	0-9	Off
	10-91	Gobo clockwise rotating
	92-173	Gobo Counter-clockwise rotating
	174-255	Gobo rotating back and forth
12 Prism	0-7	No prism
	8-36	Prism
	37-73	Prism 1 macro
	74-110	Prism 2 macro
	111-147	Prism 3 macro
	148-184	Prism 4 macro
	185-221	Prism 5 macro
	222-255	Prism 6 macro
13 Prism rotating	0-9	Prism shut
	10-91	Prism clockwise rotating
	92-173	Prism counter-clockwise rotating
	174-255	Prism rotating back and forth
14 Frost	0-255	Linear frost
15 Focus	0-255	Focus
16 Zoom	0-255	Linear zooming
17 Reset	0-79	No function
	80-100	Auto
	101-255	Reset

