

XS 4

Moving head

Function		DMX Value
1	1: Pan	0-255: Pan 540 degree
2	2: Pan: fine	0-255: Pan fine
3	3: Tilt	0-255: Tilt 270 degree
4	4: tilt: fine	0-255 Pan fine
5	5: Pan/tilt: speed	0-255: Pan & tilt speed adjustment
6	Function	130-139 lamp on
		140-149 Pan & tilt reset
		150-159 color wheel reset
		160-169 Gobo wheel reset
		170-179 strobe reset
		180-189 zoom/focus/prism reset
		200-209 complete reset
		230-239 lamp off
7	Color: Wheel	0 white
		9 dark red
		18 dark blue
		27 yellow
		37 green
		46 carmine
		55 skyblue
		64 red
		73 dark green
		82 amber
		91 blue
		101 orange
		110 CTO
		119 uv

Function		DMX Value
7	Color: Wheel	128-129 white
		130-134 dark red
		135-138 dark blue
		139-143 yellow
		144-147 green
		148-152 carmine
		153-157 sky blue
		158-161 red
		162-166 dark green
		167-171 amber
		172-176 blue
		177-180 orange
		181-185 CTO
		186-189 uv
		190-220 clockwise rainbow effect from fast to slow
		221-224 static
		225-255 anticlockwise rainbow effect from slow to fast
8	Colour: wheel (fine: positioning)	0-255 color wheel fine
9		empty
10	Static: Gobo: Wheel	0-3 white
		4-9 Gobo 1
		10-15 Gobo 2
		16-21 Gobo 3
		22-27 Gobo 4
		28-33 Gobo 5
		34-39 Gobo 6
		40-45 Gobo 7
		46-51 Gobo 8
		52-57 Gobo 9
		58-63 Gobo 10
		64-69 white 1
		70-75 white 2
		76-81 white 3
		82-87 white 4



Function		DMX Value
10	Static: Gobo: Wheel	88-95 Gobo 1 shake
		96-103 Gobo 2 shake
		104-111 Gobo 3 shake
		112-119 Gobo 4 shake
		120-127 Gobo 5 shake
		128-135 Gobo 6 shake
		136-143 Gobo 7 shake
		144-151 Gobo 8 shake
		152-159 Gobo 9 shake
		160-167 Gobo 10 shake
		168-175 white 1 shake
		176-183 white 2 shake
		184-191 white 3 shake
		192-199 white 4 shake
		200-201 white
		202-227 clockwise from fast to slow
		228-229 static
		230-255 anticlockwise from slow to fast
11	Spot: Gobo: Wheel	0 White
		1-4 the biggest fixed open circle
		5-7 spot Gobo 1
		8-10 spot Gobo 2
		11-13 spot Gobo 3
		14-16 spot Gobo 5
		17-19 spot Gobo 6
		20-22 spot Gobo 7
		23-25 spot Gobo 8
		26-28 spot Gobo 9
		29-31 spot Gobo 1 auto rotating
		32-34 spot Gobo 2 auto rotating
		35-37 spot Gobo 3 auto rotating
		38-40 spot Gobo 4 auto rotating
		41-43 spot Gobo 4 auto rotating
		44-46 spot Gobo auto rotating



Function		DMX Value
11	Spot: Gobo: Wheel	47-49 spot Gobo 6 auto rotating
		50-52 spot Gobo 7 auto rotating
		53-55 spot Gobo 8 auto rotating
		56-59 spot Gobo 9 auto rotating
		60-67 spot Gobo 1
		68-75 spot Gobo 2
		76-83 spot Gobo 3
		84-91 spot Gobo 4
		92-99 spot Gobo 5
		100-107 spot Gobo 6
		108-115 spot Gobo 7
		116-123 spot Gobo 8
		124-129 spot Gobo 9
		130-1371 spot Gobo 1 auto rotating
		138-145 spot Gobo 2 auto rotating
		146-153 spot Gobo 3 auto rotating
		154-161 spot Gobo 4 auto rotating
		162-169 spot Gobo 5 auto rotating
		170-177 spot Gobo 6 auto rotating
		178-185 spot Gobo 7 auto rotating
		186-193 spot Gobo 8 auto rotating
		194-199 spot Gobo 9 auto rotating
		200-201 white
		202-227 Gobo clockwise from fast to slow
		228-229 static
		230-255 Gobo anticlockwise from slow to fast
12	Spot Gobo auto rotating	1-127 Gobo rotating from fast to slow
		128-255 Gobo rotating anticlockwise from slow to fast
13	Rotating Gobo position	0-255 auto rotation fine
14	Prism	0-255 auto rotation fine
		0-19 open circle
		20-49 prsn 1 static
		50-75 prism rotation
		76-105 prism 1 static



Function		DMX Value
14	Prism	106-127 prism 2 rotating
15	Prism: Rotating	0 static prism
		1-127 clockwise from fast to slow
		128-129 static
		130-255 anticlockwise from slow to fast
16	Frost	0-255 linear frost
17	Zoom	0-255
18	Zoom: Fine	0-255
19	Focus	0-255
20	Focus: fine	0-255
21		empty
22	Strobe	0-31 strobe off
		32-63 strobe on
		64-95 strobe from fast to slow
		96-127 strobe on
		128-143 strobe on from fast to slow
		144-159 shutter from slow to fast
		160-191 strobe on
		192-223 random strobe from slow to fast
		224-255 strobe on
23	Dimmer	0-255 0-100%
24	Dimmer: Fine	0-255 dimmer fine

